




QUICK START GUIDE



Version 1.0

1.How to use the I-Beam


1



2




3




4

2.How to use the U-Beam


1




2




3




4



5




6




3.How to use the Link-Rod


1




2



3




4




4.How to use the Plate&Disk



1




2




3



4




5




6

5.How to use the Angle-Bracket


1




2



3




4




6.How to use the Motor-Bracket


1




2




3



4




5




6.How to use the Motor-Bracket


6




7



8




9




7.How to use the Timing Belt Wheel

1




2




7.How to use the Timing Belt Wheel

3




4




7.How to use the Timing Belt Wheel

5




6




8.How to use the P-Bracket


1




2



3




4




9. How to use the Axis-Connector


1




2



3




4




9.How to use the Axis-Connector


5



6



7



8

